SONY®

HDD-1000ヘッドクリーニングのお願い

作業を始める前に：

毎日の作業開始時、ヘッドドラムとテープ走行部を、クリーニング液(9-919-573-00)を浸したクリーニングクロス(3-731-449-01)でよく拭き、次に乾いたクリーニングクロスで拭き取って下さい。

テープを交換する時：

テープを交換する際は、新しいテープを通す前に乾いたクリーニングクロスでヘッドドラムと固定ヘッドを5～6回から拭きして下さい。

ヘッドクリーニングの方法：

2枚重ねにしたクリーニングクロスを、ヘッド先端が当たるのが微かに判る程度に、ヘッド部分に軽く押し当てて下さい。次にこの状態でゆっくりと上ドラムを5～6回手で回して下さい。ドラム走行方向に対して垂直の方向に力を加えないよう注意して下さい。

ヘッドがクロッグした時：

すぐにテープを完全に巻き戻し、ヘッドをクリーニングして下さい。

注意：クリーニングクロスが汚れた場合、洗濯することにより再使用出来ます。クリーニングに関する詳細は、メインテナンスマニュアルのセクション5-2をご覧下さい。

INSTRUCTION OF HDD-1000 HEAD CLEANING

Before start operation;

As the first thing in each morning, clean carefully both drum heads and tape transport parts by cleaning cloth(part number (3-731-449-01)moistened with cleaning liquid(9-919-573-00), followed by wiping with dry cloth.

When tape completely rewound;

Clean both drum heads and stationary heads by wiping 5-6 times with dry cloth, whenever changing tape before threading.

Method of head cleaning;

Using a folded cleaning cloth, press the head area lightly so that you can slightly feel the head projection through two layers of cleaning cloth. Manually rotate the upper drum slowly 5-6 times. Do not apply any force to the heads perpendicular to the drum scan direction.

If head is clogged;

Completely rewind the tape immediately and clean the heads.

Note: If the cleaning cloth becomes dirty, it can be washed and used again.

For more details of the cleaning, refer to section 5-2 of the maintenance manual.

2-454-570-01Ⓕ